




# CABINET PARTS

For Models: LEN2000LW0, LEN2000LG0  
(White/Grey) (Biscuit/Gold)

29" ELECTRIC DRYER



1  
Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Models: LEN2000LW0, LEN2000LG0  
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8535829	Instructions, Installation
	LIT8522243	Use & Care Guide
	LIT3406661	Wiring Diagram

## Following May Be Purchased

### DO-IT-YOURSELF REPAIR MANUALS

	LIT677818	Dryer
2	343641	Screw, 10-16 x 1/2
3	693995	Screw, 8-18 x 3/8
5	3396795	Cover, Block
6	342043	Screw, 10-32 x 3/8
7	3396805	Panel, Rear
10	3406107	Door Switch Assembly
11	697773	Screw, 6-20 x 7/8
13	3357011	Screw, 10-16 x 1/2
14	692495	Spring, Door (2)
15	3394083	Clip, Front Panel (2)


Illus. No.	Part No.	DESCRIPTION
16	3392100	Foot, Dryer
	279810	Foot-Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18		Cabinet
	8530603	White
	8530606	Biscuit
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Panel, Front
	695620	White
	3977244	Biscuit
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
26	337189	Clip, Hinge (2)
27	694091	Screw, 8-18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
33	696144	Strike, Door
35	695737	Door, Rear
36		Door, Front
	3393549	White
	3977241	Biscuit

Illus. No.	Part No.	DESCRIPTION
37		Handle, Door
	690270	White
	3977242	Biscuit
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	697776	Screw, 10-32 x 5/8
41	3397659	Block, Terminal
51	238088	Hinge, Top (2)
53	3394332	Idler & Slide Assembly
56	8066065	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16-18 x 3/4
59	3394341	Pulley, 60 Hz.
62	661654	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3390731	Seal, Door
68	3393008	Screw, 10-16 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Models: LEN2000LW0, LEN2000LG0  
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS


For Models: LEN2000LW0, LEN2000LG0  
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console	14	3400859	Screw, Grounding	33	3397269	Connector (Timer)
2	3401684	Wire, Jumper (Black)	15	3395683	Connector (Motor)	34	3347243	Connector 6-Circuit
3	693995	Screw, Hex Head	16	8271390	White Top	35	94614	Terminal
4	8271365	Cap, End (L.H.) White		8271392	Biscuit	39	3398095	Switch, Push-To-Start
	8271368	Biscuit	17	8316540	Knob, Control (3) LEN2000LW0	48		Timer Knob Assembly
6	388326	Screw, Console		8316545	LEN2000LG0		8316538	LEN2000LW0
7	694419	Buzzer, Mini	18	3394427	Clip-Harness		8316549	LEN2000LG0
8	8271359	Cap, End (R.H.) White	19	297535	Bumper, Lint Lid	50	3936144	Connector
	8271362	Biscuit	20	3401144	Connector, (PTS Relay)	51	3390537	Control, Electronic
9	8530152	Switch, Temperature	21	3406725	Timer, 60 Hz.	52	3391885	Connector, Edge
10	349639	Screen, Lint	22	3405154	Switch, Wrinkle Shield	53	8271418	Bracket, Control
11		Cover, Lint Screen	23	3955775	Medallion	54		Panel, Control (Includes Illus. 23)
	8283378	White	29	3390646	Screw, Mounting (8-18 x 5/16)		8532619	Grey
	8283380	Biscuit	30	357213	Nut, Push-In (2)		8532620	Gold
12	3978605	Hinge, R.H.	31	8299889	Harness, Wiring	55	343641	Screw, 10-16 x 1/2
	3978606	Hinge, L.H.						
13	688983	Screw, 8-18 x 5/8						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: LEN2000LW0, LEN2000LG0  
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: LEN2000LW0, LEN2000LG0  
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly	13	343641	Screw, 10–16 x 1/2	34	3402841	Lens, Drum Light
2	487909	Screw, 8–15 x 1/2	14	3397566	Box, Heater	41	690997	Ring, Tri
3	3388703	Washer–Support	15	3977767	Thermostat, 221°F (105°C)	42	3399506	Shaft, L.H.
4	347139	Seal, Lint Chute	16	3977373	Bracket, Drum Light	43	3399507	Shaft, R.H.
5	90767	Screw, 8–18 x 3/8	17	3403585	Element, Heater	44	3397588	Roller, Support
6	696302	Shield, Exhaust	18	8066086	Drum Hole Plug	46	348197	Washer, Support
7	3392519	Thermal Fuse	19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)	47	3359452	Nut, 3/8–16
8	8318268	Thermostat, Internal–Bias	20	489463	Screw, 8–18 x 5/8	48	3403414	Bulkhead
9	3977393	Thermal Cut–Off (Includes Illus. 15)	21	3390647	Screw, 8–18 x 1/2	49	3403634	Socket Assembly
10	694089	Wheel, Blower (Includes Illus. 22)	22	3394196	Seal, Blower	62	692526	Ring, Bearing (2)
11	3405016	Housing, Blower	30	3976479	Pad, Sensor	63	97787	Screw, 11–16 x 3/4
12	3398161	Clip	33	3406124	Bulb	66	3406130	Seal, Rear Drum
						67	695587	Drum Assembly
						68	692490	Baffle, Drum (2)
						69	3976434	Bracket, Support
						70	90296	Clip
						71	3403636	Baffle, Drum (1)
						73	339956	Seal

## OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

### ACCESSORY PARTS

3406839	Dry Rack
8522199	Kit, Dryer Vent Testing
279948	Kit, Dryer Repair

### PAINT, TOUCH–UP (1/2oz.)

72017	White
4392899	Biscuit

### PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
350938	Primer, Gray

### PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST